


DSP3000 Hard Wire Stop Function(HWS) NEW!

Hard Wire Stop (HWS)

The hard wire stop (HWS) function is a safety function that shuts off the motor current with a hard wire.






This safety function has not received safety certification by a third-party organization. Please consider carefully when examining the safety level etc. of each standard.

Controller & Cable

Controller	MFCT-S024S
	MFCT-S060S
	MFCT-S120S
I/F Cable	C30-HW1-M* (max:3m)

Bottom view of controller



NOTE) Specifications and designs of the products are subject to change without notice due to improvements.



https://www.daiichi-dentsu.co.jp sales@daiichi-dentsu.co.jp Head office: 1-54-1, Shimoishihara, Chofu-City,

Tokyo 182-0034,Japan Phone: 81-42-440-1465 Fax: 81-42-440-1436

Kani Plant: 690-1, Omori, Kani-City, Gifu, 509—0238, Japan Phone: 81-574-62-5865 FAX: 81-574-62-3523